



**Edelbrock E-Force Supercharger**  
**2007-2012 GM SUV**  
**4.8L, 5.3L, 6.0L, 6.2L**  
**Part # 1564, 1567**



## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

## INTRODUCTION

Thank you for purchasing the Edelbrock E-Force Supercharger System for 2007 to 2012 GM SUVs. This supercharger utilizes Eaton's new Gen VI TVS rotors, featuring a four lobe design with a full 160°. of twist for maximum flow, minimum temperature rise, quiet operation, and the reliability for which Eaton is known. The Edelbrock Supercharger is a complete system that maximizes efficiency and performance by minimizing air restriction into, and out of, the supercharger. This results in maximum airflow, with minimal temperature rise and power consumption. The supercharger housing itself is integrated into the intake manifold for a seamless design with minimal components, eliminating the possibility of vacuum leaks between gasket surfaces. The system also utilizes a front drive, front inlet configuration giving it the shortest, least restrictive inlet path on the market. The supercharger is inverted, expelling the air upward. Air pressure then builds in the plenum, before being drawn down through each of two intercooler cores, oriented horizontally, next to, and below the supercharger outlet. After passing through the intercooler cores, the air travels through the long 12" runners, which route underneath the supercharger housing to the cylinder head ports, in a horizontal, nested configuration. The upper plenum area is enclosed by a top cover that has been designed to provide an appealing and distinctive under-hood appearance. This configuration allows for a compact package that can fit under the stock hood and cowl of the vehicle, without sacrificing runner length, or intercooler area. The E-Force supercharger features a uniquely styled plenum. The Edelbrock supercharger provides neck snapping performance that is safe to operate on a completely stock engine. It is 50-state emissions legal, and can be had with an optional 5-Year x 100,000 mile warranty so that there are no worries when installing it on a brand new car.

## TOOLS AND SUPPLIES REQUIRED

- Jack and Jack Stands  
OR Service Lift
- Panel Puller
- Ratchet and Socket Set including: 1/4", 7mm, 8mm, 10mm (standard, deep and universal), 11mm, 12mm (deep), 13mm, 14mm, 15mm, 18mm, 21mm (deep), 24mm
- Wrenches including: 8mm, 10mm, 14mm, 15mm, 27mm
- 12" Ratchet Extension Bar
- 1/2" Breaker Bar
- Flat Blade & Phillips Screwdrivers
- Compressed Air
- Torx - T20, T25, T30 Driver
- Allen Wrenches including: 5mm, 6mm, 8mm
- 2" Long 5mm Allen Socket
- 3/8" Fuel Line Removal Tool
- Torque Wrench
- Needle Nose Pliers
- Bench Vice OR C-Clamp
- Hose Clamp Removal Tool
- Grinding Tool (Dremel) or equivalent
- Pneumatic OR Right Angle Power Drill
- Drill Bits: 5/32"
- Punch
- Impact Wrench
- Red Loctite or equivalent
- Permatex Thread Sealant w/ PTFE, or equivalent
- O-ring Lube
- Anti-seize
- Masking Tape
- Shop Rags
- Zip Ties / Wire Ties
- J-42386-A Flywheel Holding Tool
- 50/50 Coolant Mixture



**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

## **Installation Instructions**

### **IMPORTANT WARNINGS**

**Before beginning installation, use the enclosed checklist to verify that all components are present in the box then inspect each component for damage that may have occurred in transit. If any parts are missing or damaged, contact Edelbrock Technical Support (1-800-416-8628), not your parts distributor.**



**WARNING:** *Installation of this supercharger will result in a significant change to the performance characteristics of your vehicle. It is highly recommended that you take some time to familiarize yourself with the added power, and how it is delivered, in a controlled environment. Take extra care on wet and slippery roads, as the rear tires will be more likely to lose traction, with the added power. It is never recommended to turn off your vehicles traction control system.*

**Please employ proper towing etiquette when towing steep grades. Turn off Air Conditioner and avoid aggressive towing behaviors to avoid any overheating that may occur. DO NOT exceed the manufacturer's maximum tow rating for the vehicle.**

**Proper installation is the responsibility of the installer. Improper installation will void all manufacture's standard warranties and may result in poor performance and engine or vehicle damage.**

Due to the complexity of the Edelbrock E-Force Supercharging system, it is recommended that this system only be installed by a qualified professional with access to a service lift, pneumatic tools, and a strong familiarity with automotive service procedures. **To qualify for the optional supplemental warranty**, it is necessary to have this system installed by a Certified ASE Technician, GM Dealership, or an Authorized Edelbrock Installer. Failure to do so will void and/or disqualify any and all optional supplemental warranties offered with this system. Please contact the Edelbrock Technical Support department if you have any questions regarding this system and/or how your installer of choice will affect any warranty coverage for which your vehicle may qualify.

**Any previously installed aftermarket tuning equipment must be removed and the vehicle returned to an as stock condition before installing the supercharger.**

Any equipment that directly modifies the fuel mixture or ignition timing of the engine can cause severe engine damage if used in conjunction with the Edelbrock E-Force Supercharger System. This includes, but is not limited to: ignition boxes, air/fuel controllers, OBD-II programmers, and any other device that modifies signals to and/or from the ECU. Aftermarket bolt-on equipment such as underdrive pulleys or air intake kits will also conflict with the operation of the supercharger and must be removed prior to installation. Use of any of these products with the E-Force Supercharger could result in severe engine damage.





**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

**Installation Instructions**

**IMPORTANT WARNINGS (CONTINUE)**

**Edelbrock periodically releases improved versions of the calibration file found on the supplied handheld programmer. Check the website to ensure you have the latest version, as described on page 10.**



**91 octane or higher gasoline is required at all times. If your vehicle has been filled with anything less, it must be run until almost dry and refilled with 91 or higher octane gasoline twice prior to installation.**

**NOTE: If a supplemental fuel pump kit is required for installation, the tank can be drained once removed from the vehicle.**

**Any failures associated with not using premium 91 octane gasoline or higher, will be ineligible for warranty repairs.**

**THE FLEX-FUEL FUNCTION HAS BEEN DISABLED. DO NOT USE ANY GASOLINE WITH AN ETHANOL RATING HIGHER THEN 10% (E10). FAILURE TO DO SO WILL RESULT IN ENGINE DAMAGE AND VOID YOUR WARRANTY**

**NON-Flex Fuel vehicles will require Edelbrock's Supplemental Fuel Pump Kit (details below and on next page). Please visit our website or call our Tech line at 1-800-416-8628 for more information.**

**! WARNING**

**SUPPLEMENTAL FUEL PUMP KIT**

*(Required for 2007-2009 Non-Flex Fuel Vehicles - SOLD SEPARATELY)*

**DESCRIPTION:** The supplemental fuel pump kit includes a replacement fuel pump, fuel level sending unit, fuel pump control module and fuel injectors (#15671 and 15672 only). This upgrade kit is required for some GM SUVs utilizing the #1564 and #1567 E-Force supercharger system (see kit and model breakdown below). **Failure to use the supplemental fuel pump kit may result in engine damage and void your Edelbrock E-Force Supercharger's warranty.** This supplemental fuel pump kit is not needed and will not work on Flex- Fuel models. Flex Fuel models come standard with adequate fuel systems that properly operate with the Edelbrock E-Force Supercharger system.

*Supplemental Fuel Pump Part Numbers.*

**#15642** - 07-09 – 4.8/5.3L, GM SUV, Short Wheel Base

**#15671** - 07-09 – 6.0/6.2L, GM SUV, Short Wheel Base

**#15643** - 07-09 – 4.8/5.3L, GM SUV, Long Wheel Base

**#15672** - 07-09 – 6.0/6.2L, GM SUV, Long Wheel Base

*Kit includes the following:*

1 - Fuel Pump

8 - Fuel Injectors and O-Rings (P/N 15671 and 15672 Only)

1 - Fuel Level Sending Unit

1 - Fuel Pressure Control Module




**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

**Installation Instructions**

**Please refer to the vehicle break down below to determine if your vehicle requires a supplemental fuel pump kit.**

Locate your Vehicle Identification Number (VIN). Using the guide below, verify that VIN digit 8 is a C or J for vehicles with 4.8/5.3L engines or a Y or 8 for vehicles with 6.0/6.2L. If a C, J, Y or 8 is present, your vehicle will require a supplemental fuel system. Please use the chart below to identify the supplemental fuel pump kit needed for your vehicle.

Supplemental Fuel Pump Kit	Engine Type - VIN Digit 8	Body Type - VIN Digit 7
P/N 15642	C or J	2
P/N 15643	C or J	6
P/N 15671	Y or 8	2
P/N 15672	Y or 8	6



**INSTALLATION NOTE:**

*It is critical to install the supplemental fuel pump kit on a vehicle that is able to start once the installation is complete. Once the supplemental fuel pump kit is installed, you must start the vehicle to check for leaks and check engine lights. This installation can be performed prior or after the supercharger installation. If performed after the supercharger installation, DO NOT DRIVE the vehicle without installing the supplemental fuel pump kit first.*

**Please visit our website or call our Tech line at 1-800-416-8628 for more information.**




**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

**Installation Instructions**

**INSTALLATION HARDWARE IDENTIFICATION GUIDE**

**Bag #1**



**Bag #2**



**Bag #3**







**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

**Installation Instructions**

**Bag #4**

(1x) - GM Factory Harmonic Balancer Bolt



(1x) - M16 x 2 x 120mm Hex Bolt



(1x) - Crank Pinning Drill Guide

(1x) - 15/64" High Speed Steel Drill Bit



(1x) - 1/4" x 3/4"  
Steel Dowel



(1x) - .2500" Reamer



**SUV Hardware Bag**



(1x) - Hood Damper  
Support Bracket



(1x) - Hood Damper  
Support Bracket - Rear

(1x) - Ball Joint  
Adapter



(2x) - Washer M8



(2) 1" Spacer



(3x) - M8 Nut



(2x) - M6 x 1 x 35mm  
Hex Flange Bolt



(2x) - M8 x 1.25 x 30mm  
Hex Flange Bolt




(1x) - Bolt M8 x 20mm



(1x) - Sheet  
Metal Screw



**HOSE IDENTIFICATION GUIDE**







**HOSE IDENTIFICATION GUIDE CONTINUED**

Driver side PCV  
Valve Cover to Manifold Nose



Passenger Side PCV  
Valve Cover to Intake



EVAP to Manifold



Brake Booster Hose






**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

**Installation Instructions**

**WIRE HARNESS GUIDE**






**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

**Installation Instructions**

**HOSE ROUTING GUIDE**





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L


### Installation Instructions

#### Test Flash Procedure

Verify that your vehicle's ECU & the supplied programmer are up to date, then use the programmer to flash the ECU thus verifying that they are compatible

- Original Equipment Manufacturers often release updates to the computer programming for your vehicle. Edelbrock highly recommends that you verify, with your new car dealer, that your vehicle is equipped with the latest software version from your vehicle manufacturer, before attempting to load the Edelbrock tune.
- Confirm that your programmer has the latest calibration by checking the Edelbrock website ([http://www.edelbrock.com/automotive\\_new/mc/superchargers/software-tech.shtml](http://www.edelbrock.com/automotive_new/mc/superchargers/software-tech.shtml)) Once you have found the latest tune on the site, power on the programmer, press the left arrow and select the Device Info option. Scroll down to Tune Version and compare that number to the one on the site. If they are different, download the new calibration as instructed on the website.
- Turn the key to the "ON" position, but don't start the vehicle.
- Connect the supplied PCM cable to the OBD-II connector located below the steering wheel and to the left of your knee.
- Use directional pad to highlight Program Vehicle option and press Select button.
- Use directional pad to highlight Pre-programmed Tune option and press Select button.
- Read disclaimer then press Select to continue.
- Verify ignition is in the 'Key On' position but that the engine is not running then press Select.
- Use directional pad to highlight your vehicle and transmission combination then press Select.
- Use directional pad to highlight Begin Program then press Select.

- Depending on your specific drivetrain configuration, several separate operations may take place during this step. Completion of each operation will cause the progress bar to reset to zero.



#### **DO NOT unplug the programmer until prompted.**

- Turn the car off when prompted to do so by the handheld programmer.
- Read parting message from programmer then press Select to continue.
- Unplug the programmer cable from the OBD-II port.

In the rare occurrence that you encounter an error message during the test flash procedure, please refer to pg. 32, titled Email Edelbrock Your Stock PCM Calibration.

#### Post Successful Test Flash

If you are ready to install the supercharger, proceed to Step 1 of the Supercharger Installation.

OR

If you wish to return the ECU back to the factory calibration, such that the vehicle can still be driven until you are ready to begin the installation, then:

- Turn the key to the "ON" position, but don't start the vehicle.
- Connect the supplied PCM cable to the OBD-II connector.
- Use directional pad to highlight Program Vehicle option and press Select button.
- Use directional pad to highlight Return To Stock option and press Select button.






## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

- Follow the on screen instructions.
- Turn the key to the “OFF” position when prompted to do so by the handheld programmer.
- Read parting message from programmer then press Select to continue.
- Unplug the programmer cable from the OBD-II port.
- When you are ready to Install the supercharger, proceed with Step 1 and you will be prompted to re-flash the ECU towards the end of the installation procedure.

#### Supercharger Installation

1. Using a 10mm socket, remove the negative battery cable.
2. Remove radiator shroud using a flat blade screwdriver to pry up the heads of the six (6) push-pins, then use a panel puller to fully remove the push pins. Lift the radiator shroud off the vehicle and set aside along with the push-pins.



3. Using a 10mm socket, remove the six (6) top support bolts securing the fascia.



4. Using a 7mm socket and a panel puller, remove two (2) bolts (red arrow) and two (2) push pins (green arrow) securing the wheel liner from the passenger and driver side wheel well.



5. Using a 10mm socket, remove four (4) bolts from the bumper/fender support brackets. Two (2) from the driver side and two (2) from the passenger side.



6. Using a 10mm socket, remove two (2) bolts from the bumper support brackets. One (1) from the driver side, the other from the passenger side. Unplug the fog lamps if equipped and carefully remove the fascia and set aside.





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

7. Remove the engine cover by lifting the front of the cover up to detach the clips, then lift the rear of the cover to fully remove.

8. Remove the passenger side PCV tube by un-clipping it from the passenger side valve cover. Now remove the air intake tube by loosening the two (2) worm clamps and pulling the tube off the throttle body and the airbox.



9. Using a 15mm socket and a breaker bar, remove the serpentine belt by rotating the tensioner clockwise until the belt can slide off the idler pulley.

10. Unplug the alternator connector and remove the power cable using a 10mm socket. Now remove the two (2) bolts, using a 15mm socket to fully remove the alternator.



11. Remove the idler pulley on the alternator bracket using a 15mm socket.

**NOTE:** Hardware from this idler pulley (bolt, washer and bushing) will be reused later.



12. Remove the top engine harness retainer bracket by removing the three (3) bolts using a 10mm socket. Then unravel the retainer bracket from the engine harness to remove the retainer bracket completely (if equipped).



13. Disconnect and remove the driver side PCV tube located on top of the manifold and driver side valve cover.



14. Disconnect the EVAP solenoid hoses and unplug the EVAP harness. Then unplug the MAP harness from the MAP sensor and ETC harness from the throttle body.

**CAUTION:** Use care when removing the clip on the ETC plug, as they break easily.



15. Remove the brake booster hose from the check valve.

**NOTE:** Retain the check valve for re-use.







## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

16. Using a 10mm socket, remove the bracket securing the heater hoses.



17. Disconnect all eight (8) injector plugs (four driver side, four passenger side).



18. Remove the plastic cap on the schrader valve located on the passenger side fuel rail. Place a towel over the schrader valve and carefully release the pressure from the fuel system using a small flat head screwdriver or equivalent.



19. Remove the fuel hose safety clip, then remove the fuel supply line using a 3/8" Fuel Line Removal Tool.



20. Unhook the main engine harness from the rubber hooks on the intake manifold and move the harness behind the manifold.

21. Remove the manifold by loosening the ten (10) bolts with an 8mm socket.

22. Use a clean shop rag to wipe down the intake flange of both cylinder heads. Apply masking tape to the head ports to prevent any dirt or debris from entering the ports.

23. Unplug the coil pack main harnesses and the coil boots. Then remove the driver & passenger side coil bracket assemblies by removing five (5) bolts (on each side) using a deep 10mm socket.



24. Using a small flat head screwdriver or equivalent, remove the plastic covers from the coil brackets (these will not be re-used).







## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

25. Remove the factory valley tray, by unplugging the oil pressure sensor and the Active Fuel Management (AFM) system (if applicable). Use a 27mm wrench to remove the oil pressure sensor from the valley tray. Unbolt the eleven (11) bolts securing the valley tray using a 13mm socket.



**NOTE:** Steps 26-34 outline the procedure for disabling the Active Fuel Management (AFM) system. If your vehicle is not equipped with the AFM system, proceed to Step 35.

**TIP:** Valley trays with AFM systems will have solenoids attached to the backside of the valley tray as pictured below. Valley trays without AFM systems will not.

**There are two (2) variants of the AFM valley trays:**

- Use Steps 26-30 if your solenoid assembly is secured to the valley tray with Torx bolts.
- Use Steps 31-34 if your solenoid assembly is secured to the valley tray with rivets.

26. Use a T-20 Torx driver to remove the four (4) bolts retaining the plastic solenoid bracket, then pry open the clip at the rear of the plate to remove the bracket.




27. Rotate each solenoid 90° clockwise and remove.



28. Use a T-30 Torx driver to remove the twenty (20) bolts holding the steel sandwich in place and remove.

29. Carefully remove the plastic and rubber gasket from the valley tray. Do not discard or damage the seal as it will be reused.

30. Trim the two (2) bosses projecting from the gasket to the base of their tapers to allow the valley tray to sit flush when installed (verify proper clearance before installing). Use a file to remove any burrs, then install the gasket onto the new valley tray. Proceed to Step 38.



**NOTE:** Steps 31-34 only applies to vehicles with solenoid assemblies which are secured to the valley tray with rivets. Disregard otherwise.



31. Using a cutoff wheel or equivalent, cutoff eleven (11) rivets securing the solenoid assembly onto the valley tray. Be careful not to damage the gasket as it will be reused.







## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L


### Installation Instructions

32. Remove the solenoid assembly from the valley tray and carefully remove the gasket.




33. Using a precision grinding tool, grind down six (6) bosses on the gasket until they are flush with the gasket.

**NOTE:** Be careful not to damage the perimeter seals of the gasket.



34. Using a 5/32" drill bit, drill out four (4) bleed holes in between the lifter bosses as shown. Place the gasket onto the supplied valley tray to verify that the drilled holes are aligned with the grooves on the valley tray. Clean the gasket to remove any debris and install onto the supplied valley tray. Proceed to Step 38.




**NOTE:** Steps 35-37 are for Non-AFM vehicles. Disregard if your vehicle is equipped with an AFM system.


35. Place shop rags inside the opening of valley tray to prevent foreign objects from falling into the engine block openings.

36. Using a little clean engine oil, install eight (8) provided O-rings onto the eight (8) top caps if not already done so.

37. With clean, oil free hands, carefully install the top caps in the eight (8) locations shown below. Be careful not to drop the top caps as they may enter the engine block. Now install the provided valley tray gasket.



38. Using a 5mm Hex tool, install the valley tray using eleven (11) supplied M8 x 25mm countersunk bolts in Bag #3. Apply anti-seize to the taper undersides of the bolt heads and tighten in a criss cross pattern starting from the inside and working outwards. Torque bolts to 18 ft/lbs (25 Nm).





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L


### Installation Instructions

39. Apply Permatex Thread Sealant w/ PTFE, or equivalent, to the threads on the oil pressure sensor and reinstall. Torque to 26 ft/lbs (35 Nm).

**NOTE:** DO NOT use Teflon tape as it will not seal properly.

40. Raise the front of the vehicle using a service lift or equivalent. Remove four (4) bolts securing the skid plate using a 15mm socket (if equipped).

41. Unbolt the starter by removing two (2) bolts with a 13mm socket. Now remove the flywheel cover using a 10mm socket. Move the starter aside as it is difficult and unnecessary to remove completely.



42. Install GM Flywheel Holding Tool #J-42386-A or equivalent, to prevent the crank from rotating while loosening the balancer bolt. Torque the bolts to 37 ft/lbs (51 Nm).

43. Remove the balancer bolt, using a breaker bar and a 24mm socket.

**TIP:** A long pipe slid over the breaker bar can be helpful for increasing leverage.

44. Loosely install the supplied hex bolt and reamer guide to the end of the crank. Rotate the reamer guide until the drilling bushing is at a comfortable position for drilling. Securely tighten the reamer guide and bolt using a 24mm socket.



45. Mark the supplied drill bit with a piece of masking tape. It must measure 1.6" from the tip.

46. Lubricate the drill bit with a small amount of engine oil. Then locate the guide hole with the drilling bushing. Begin drilling using a Right Angle Drill (or equivalent) and the supplied 15/64" drill bit. The drilling process is complete when the tape mark on the bit meets the guide.

47. Loosen the balancer bolt and remove any metal debris with compressed air. Rotate the guide until the ream hole lines up with new dowel pin hole on the crank. Use the supplied .2500" ream tool to verify that the holes are aligned. Then tighten the bolt and ream the hole.

48. Remove the balancer bolt and reamer guide. Clear out any remaining metal debris with compressed air. Apply Red Loctite, or equivalent, to the supplied dowel pin and gently tap it into the new dowel pin hole until it is flush.

49. Install supplied balancer bolt onto the crank. Torque it to 37 ft-lbs (51 Nm), then rotate it an additional 140° using a breaker bar.

50. Remove the GM Flywheel Holding Tool and reinstall the flywheel cover and starter using the factory bolts. Torque starter bolts to 37 ft-lbs (51 Nm).

51. Drain the coolant (as needed) by removing the petcock from the radiator (or by removing lower radiator hose). Coolant level must be below cylinder head coolant bleed pipes/crossover to prevent coolant overflow in the next step. Reinstall the petcock.

52. Using pliers, remove coolant feed hose from coolant crossover. Now remove coolant crossover using a 10mm socket.







## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

53. Using a razor blade or equivalent, remove the rubber guard on the factory coolant crossover and install it onto the supplied coolant crossover.



54. Using a 10mm socket, install the supplied coolant crossover using the factory bolts, making sure the inlet port is on the driver side. Reinstall the factory coolant feed hose to the crossover.



55. Remove the rear engine support brace attached to the rear of the driver side cylinder head using a 15mm socket.



56. Two (2) of the stock intake manifold bolt holes in the cylinder heads break into the crankcase and are not used with this supercharger. Remove the tape covering the intake ports. Install two (2) button head bolts supplied in Bag #3 in the front passenger side and rear driver side intake manifold bolt holes.

**NOTE:** Steps 57-58 are for vehicles equipped with 4.8L/5.3L engines. Disregard if vehicle is equipped with 6.0L / 6.2L engine and proceed to Step 59.

57. Remove the gaskets on the factory intake manifold if not already done so. Using side cutters or equivalent, trim down the three (3) retention clips and the center locating tab. Use CAUTION while trimming the clips. Re-inspect the gaskets after modification for any tears and replace as necessary. Install onto the manifold to verify a flush fit.




58. Install the modified intake manifold gaskets onto the supercharger manifold using the installed bushings as guides. Proceed to Step 60.



**NOTE:** Step 59 only applies to vehicles with 6.0L / 6.2L engines. Proceed to Step 60 if your vehicle is equipped with a 4.8L or 5.3L engine.

59. Install the eight (8) supplied manifold O-ring gaskets to the manifold ports as shown below.





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

60. Connect the supplied TMAP harness to the MAP sensor on the back of the supercharger. Bundle the harness up and wrap over the top of the manifold to avoid damage during installation of the supercharger.



61. Remove protective tape from cylinder ports. Spray silicone lubricant or equivalent, onto the cylinder heads to help align the supercharger manifold.


**NOTE:** Supercharger manifold is very heavy. The following step should be performed with more than one person, an engine hoist, or equivalent.

Be careful not to pinch the TMAP harness or break the manifold gaskets, as broken gasket debris can fall into the cylinder head ports.

62. Carefully lower the manifold onto the engine so that the bushings set properly (Only applies to 4.8L and 5.3L).

**NOTE:** Check to make sure there are no gaps between the gaskets and the manifold as well as the gaskets and the cylinder heads. On 6.0L and 6.2L, the manifold should sit flush with the cylinder heads.

63. Secure the manifold using eight (8) supplied M6 x 45mm bolts in Bag #3. Using a 10mm socket with universal joint, tighten the bolts according to the torque sequence diagram below. Torque the bolts to 44 in/lb (5 Nm). Then re-torque in the same sequence to 89 in/lb (10 Nm).



64. Remove the factory installed O-rings from the supplied injectors on the outlet port. Lightly apply O-ring lube to the supplied larger O-rings and install them onto the injectors.

**P/N 1564, 2007-2012 4.8L/5.3L** - Use provided injectors and larger O-rings in this kit.

**P/N 1567, 2007-2009 6.0L/6.2L** - Use injectors and larger O-rings from fuel pump kit #15671 or #15672 (*Required - Not included*).

**P/N 1567, 2010-2012 6.2L** - Re-use stock injectors w/ supplied larger O-rings.

**NOTE:** The larger O-rings must be used to avoid vacuum leaks. 2010-2012 6.2L vehicles will need to remove the injectors from the factory manifold if not already done so.



65. Remove and discard the factory installed metal clips on the injectors.








## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

66. Lightly lubricate the O-rings on the fuel rail fittings. On the passenger side rail, install one (1) straight fitting on the provision nearest to the bolt hole and the black plug on the opposite end as shown. On the driver side rail, install the 90° black anodized fitting onto the provision nearest to the bolt hole and the straight fitting on the opposite end as shown. Lubricate the all O-rings on the injectors and install them into the fuel rail so that the electrical connectors face away from the supercharger.




67. Install the supplied fuel cross-over hose onto the passenger side zinc 3/8" adapter and route it behind the manifold over towards the driver side. Make sure the cross-over hose routes behind the factory fuel supply line.



68. Lower the passenger fuel rail assembly onto the manifold lining up the injectors with their provisions on the manifold. Gently, push down on the rails until the injectors are fully seated. Secure fuel rail using a 5mm Hex tool and two (2) M6 x 12mm bolts from Bag #3.

69. Attach the fuel cross over to the driver side zinc 3/8" adapter and lower the driver side fuel rail assembly onto the manifold and line up the injectors with their provisions on the manifold. Gently, push down on the rails until the injectors are fully seated. Secure fuel rail using a 5mm Hex tool and two (2) m6 x 12mm bolts from Bag #3.

70. Install the supplied fuel line extension by inserting the male end into the main fuel supply line. Then connect the extension to the 90° black anodized fitting on the driver side fuel rail.



**NOTE:** Step 71 is performed to give additional slack to the right rear injector, EVAP and alternator connectors.

71. Unravel the rear injector connector and EVAP connector approximately 2-3". Also unravel the alternator harness from the main harness about 2-3". Re-secure harness with electrical tape.



72. Re-connect all eight (8) fuel injector plugs. Reinstall the coil pack assemblies using a 10mm socket and the factory bolts. Then plug in the main coil pack harnesses and the coil pack boots.

73. Remove both ambient air temp sensors from their mounting locations on the A-frame. Some vehicles are only equipped with one ambient air temp sensor.






## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L


### Installation Instructions

**NOTE:** Chevy vehicles need to proceed with Steps 74-75 to ensure that the LTR is installed in the correct position for optimal cooling. Cadillac/GMC vehicles disregard and proceed to Step 76-77.

74. Using four (4) M6 x 10 bolts from bag #2, mount the lower LTR brackets to the lower LTR bungs ensuring that the inlet barb (passenger side barb) in the up position once the LTR is installed. Secure the lower LTR brackets to the A-Frame with two (2) M6 x 16 bolts from bag #2.




75. Secure the upper LTR bracket to the LTR with two (2) 1" spacers and two (2) M6 x 35mm bolts from the SUV hardware bag. Now secure the LTR to the hood latch location using two (2) M6 x 16 bolts along with two (2) M6 nuts. Proceed to Step 78.




**NOTE:** Cadillac/GMC vehicles need to proceed with Steps 76-77 to ensure the LTR is installed in the correct position for optimal cooling. Chevy vehicles disregard and proceed to Step 78.

76. Using two (2) M6 x 10mm bolts from bag #2, secure the upper LTR bracket to the upper LTR bungs ensuring that the inlet barb (passenger side barb) is in the up position once the LTR is installed. Now secure the LTR to the hood latch location using two (2) M6 x 16 bolts along with two (2) M6 nuts from bag #2.



77. Mount lower LTR brackets to the lower LTR bungs using four (4) M6 x 35mm bolts and four (4) 1" spacers from the SUV hardware bag and Bag #2). Secure lower LTR brackets to the A-Frame with two (2) M6 x 16mm bolts from bag #2. Proceed to Step 78.



78. Secure both ambient air temp sensors onto the lower LTR brackets as shown (one to each bracket).

**NOTE:** Vehicles equipped with one (1) ambient air temp sensor, mount to lower LTR bracket closest to sensor.








## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

79. Using a hose clamp tool or equivalent, install the water pump to LTR hose to the LTR inlet barb with one (1) 3/4" hose clamp from Bag #2. Now route the hose around the radiator shroud and AC hard lines.



80. Route the LTR to Manifold Hose along the bottom of the lower radiator fan shroud and install onto the lower passenger side manifold inlet barb. Using four (4) wire ties, secure the hose to the lower radiator shroud.



81. Install the other end of the LTR to Manifold hose onto the lower driver side manifold inlet barb.



82. Now route the LTR to Manifold hose towards the LTR as shown below, and secure it to the LTR outlet barb using one (1) 3/4" hose clamp in Bag #2.



83. Install the Manifold to Recovery Tank hose onto the upper passenger side outlet barb on the manifold.



84. Then route the hose behind the manifold and install it onto the upper driver side manifold outlet barb.





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

85. Using four (4) M6 x 16mm bolts from Bag #2, install the recovery tank bracket onto the recovery tank as shown.




86. Connect the Manifold to Recovery Tank hose to the recovery tank's inlet barb using one (1) 3/4" hose clamp. Connect the Tank to Water Pump hose to the tank's outlet barb and secure with one (1) 3/4" hose clamp. Route Tank to Water Pump hose down towards the left front of the vehicle. Then install the tank onto the two (2) front passenger side coil pack studs with two (2) M6 nuts from Bag #2.




87. Mount the water pump bracket to the side of the body over the plastic splash shield located behind the passenger side wheel well. Use two (2) M8 bolts and two (2) M8 nuts from the SUV hardware bag along with two (2) existing bolts on the frame and chassis.

**NOTE:** The center two (2) mounting locations may not be present on some vehicles. If not present, the two (2) factory bolt locations are sufficient.



88. Secure the hose from the recovery tank to the inlet barb on the water pump with one (1) 3/4" hose clamp. Secure the hose from the LTR to the outlet barb on the water pump with one (1) 3/4" hose clamp. Making sure that the water pump outlet barb is pointing up, secure the water pump to the water pump bracket using the bracket strap and one (1) M8 x 30mm bolt from Bag #2.







## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions


89. Using a small flat head screwdriver, remove the factory EVAP solenoid off the factory fuel rail assembly.



90. Install the supplied EVAP bracket onto the driver side coil pack assembly stud using one (1) M6 nut from Bag #2. Stud location is in between the first and second coil packs. Install the factory EVAP on to the EVAP bracket as shown.



91. Install the factory EVAP hose to the rear barb of the EVAP solenoid. Install the provided EVAP hose on the right rearmost barb of the manifold nose and connect it to the front barb of the solenoid. DO NOT connect the EVAP harness to the solenoid.



92. Clock the brake booster check valve approximately 90° counter clockwise. Using two (2) 1/2" hose clamps from Bag #2, install the provided brake booster vacuum hose to the brake booster check valve and to the first barb (closest to front) on the manifold nose. Reinstall the brake booster check valve harness (if applicable).



93. Install the driver side PCV hose by sliding it onto the rear barb located on the driver side valve cover. Then install it on the center barb located on the manifold nose. Be sure to route the hose between the coil bracket and intercooler hose.

**NOTE:** On earlier vehicles, the rear barb on the driver side valve cover will be outfitted with a non-quick connect barb. If this applies to your vehicle, you must remove the quick connect fitting on the supplied hose and use a hose clamp (not included) to secure the PCV hose to the valve cover barb.






## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

94. Using a bench vice or equivalent, install the bushings onto the supplied alternator bracket as shown.

**NOTE:** Use CAUTION when applying pressure to the bushings to avoid bending the bushing tabs.

**TIP:** You can use a shallow 14mm socket to protect the surface of the bracket while clamping the alternator bracket.




95. Install the rubber grommet from bag #1 into the hole located in the upper cavity of the alternator bracket. Using a 15mm socket, install the alternator bracket with the factory alternator bolts. Route the actuator hose through the grommet as shown, and re-connect to the actuator.




96. Remove the bolt, washer and bushing from the stock 90mm pulley and install them on the supplied 76mm pulley.



97. Apply Red Loctite to the threads on both idler pulley bolts. Then use a 15mm socket to install the 76mm idler pulley with the factory hardware to the left idler pulley location. Install the additional idler pulley to the right idler pulley location with one (1) M8 x 20mm bolt and one (1) M8 washer from Bag #1. Verify that both pulleys spin freely.



98. Using a small flat head screwdriver, remove the black ABS backing by releasing the three (3) locking tabs. Then remove the four (4) bolts securing the alternator housing using a 1/4" socket.







## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

99. Clock the rear portion of the alternator clockwise one bolt position so that the harness plug points at the right mounting hole. Apply red Loctite to the bolt threads and reinstall the four (4) alternator bolts and plastic cover.




100. Using a 15mm socket and the supplied M10 x 90mm bolts in Bag #1, install the alternator onto the new alternator bracket and torque to 41 ft-lbs (55 Nm). Re-connect the alternator harness plug.




101. Remove factory alternator power cable and install supplied alternator power cable to factory location (**this may be on the firewall power junction or the positive battery terminal**). Then route cable behind manifold and connect it to alternator using a 10mm socket.



102. Route the supplied serpentine belt using the diagram below. Use a 15mm socket to release tension from the tensioner and re-tension after the belt is routed.



103. Using a 10mm socket, remove the factory throttle body from the factory intake manifold. Then carefully remove the throttle body gasket as it will be reused.



104. Install the factory throttle body gasket onto the supercharger throttle body flange as shown.





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

105. Using four (4) supplied M6 x 40mm bolts in Bag #1, install the factory throttle body onto the throttle body flange.



106. Using a Torx T25, remove the factory airbox cover.



107. Replace the factory air filter with the supplied Green reusable air filter.




108. Install the supplied silicone elbow onto the airbox cover, ensuring that the PCV port is facing down. Loosely install the supplied worm clamps onto the silicone elbow as shown.



109. Reinstall the top cover by slipping the silicone elbow onto the throttle body first. Then secure the top cover using a Torx T25 and the factory airbox screws. Re-align elbow for best fitment and tighten both worm clamps.

110. Connect the previously installed TMAP harness to the factory MAF plug and then to the factory MAF sensor. Now connect the MAP connector to the factory MAP harness. Reconnect the ETC harness to the throttle body.








## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

**NOTE:** Proceed with Step 111 if your vehicle is equipped with a firewall mounted power junction. Otherwise, disregard and proceed to Step 112.

111. Using a 10mm socket, secure the fuse holder on the Water Pump harness to the left mounting stud of the power junction as shown below. Connect the POSITIVE (+) wire (orange) to the left junction terminal behind the factory power cable. Now mount the relay and GROUND (-) wire to the right stud of the power junction mounting stud as shown.



**NOTE:** Step 112 is for vehicles with battery mounted power junction. Proceed to Step 113 if your vehicle is equipped with a firewall mounted power junctions.

112. Remove the factory harness mounted on the stud on the firewall. Insert the relay GROUND (-) wire on the Water Pump harness to the stud on the firewall. Then mount the relay onto the same stud and secure with the supplied M6 nut from Bag #2. Re-mount the factory harness onto the stud. Now connect the POSITIVE (+) wire (orange) on the fuse holder to the positive terminal on the battery. Secure the fuse holder to the positive battery cable loom with a wire tie.



113. Route the EVAP solenoid connectors behind the manifold over towards the EVAP solenoid. Plug the female EVAP solenoid harness into the factory EVAP harness. Now plug the male connector into the EVAP solenoid.



114. Route the water pump connector down towards the water pump and connect it to the water pump. Secure the harness along the reservoir tank hose with wire ties.

115. Secure hood using a temporary hood prop. Using a small flathead screwdriver, loosen the metal clip on the hood dampener prop and remove prop from ball joint.



116. Remove the factory clip securing the rain guard.





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

117. Align the front and rear hood dampener brackets and loosely secure with the supplied ball joint adapter from the SUV hardware bag.



118. Position the hood dampener bracket assembly under the rain guard and align with the hole on the OE hood dampener bracket. Adjust the bracket so that it sits flush on the OE bracket and the firewall. Mark the location of the rear mounting hole with a marker.



119. Using a punch and a hammer, mark the center of the drill hole. Using a drill and a 5/32" drill bit, carefully drill out the rear mounting hole.



120. Secure the bracket to the firewall with the supplied sheet metal screw from the SUV hardware bag.



121. Using two (2) 13mm wrenches, secure the hood prop bracket to the OE bracket using the M8 bolt and M8 nut from the SUV hardware bag.



122. Tighten the ball joint adapter using a 14mm ratchet and install the hood prop onto the ball joint adapter.



123. Reinstall skid plate, front grill and upper radiator shroud.

124. Verify that the radiator petcock is reinstalled and refill the coolant system as needed.

125. Fill the intercooler recovery tank with a 50/50 blend of water and coolant. Fill the tank until the coolant mixture level is roughly 1" from the top of the threaded neck.

126. Reinstall the negative terminal on the battery.

127. Turn the ignition key to the 'ON' position but **DO NOT START THE VEHICLE YET.**

128. Carefully inspect the fuel rail, fuel hose fittings and coolant hoses for any leaks. If any leaks are detected, shut the key off immediately and make any necessary repairs before continuing.

129. With the key in the "ON" position, verify that the coolant mixture is flowing briskly through the intercooler recovery tank, then install the cap. The intercooler pump will cycle and the water level may change. Repeat Step 125 as necessary until proper mixture level is reached.





## Edelbrock Supercharger 2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L

### Installation Instructions

**If you have yet to flash your ECU, then proceed with steps 130-142, otherwise disregard them.**

130. It is recommended that you check the Edelbrock website at: ([http://www.edelbrock.com/automotive\\_new/mc/superchargers/fuel\\_injected\\_soft-tech.shtml](http://www.edelbrock.com/automotive_new/mc/superchargers/fuel_injected_soft-tech.shtml)) to confirm that you have the latest calibration. Once you have found the latest tune on the site, power on the programmer, press the left arrow and select the Device Info option. Scroll down to "Tune Version" and compare that number to the one on the site. If they are different, download the new calibration with the supplied USB cable.

131. Turn to key to the "ON" position, but don't start the vehicle.

132. Connect the supplied PCM cable on the handheld programmer to the OBD-II connector located below the steering wheel, and to the left of your knee.

133. Use the directional pad to highlight the Program Vehicle option and press the Select button.



134. Use the directional pad to highlight the Preprogrammed Tune option and press the Select button.

135. Read the disclaimer then press Select to continue.


136. Verify that the ignition is in the 'Key On' position and that the engine is not running, then press Select.

137. Use the directional pad to highlight your vehicle and transmission combination then press Select.

138. Use the directional pad to highlight the Begin Program option then press Select.

139. Depending on your specific drivetrain configuration, several separate operations may take place during this step. Completion of each operation will cause the progress bar to reset to zero.

**DO NOT unplug the programmer until prompted.**



140. Turn the vehicle off when prompted to do so by the handheld programmer.

141. Read the parting message from programmer then press Select to continue.

142. Unplug the programmer cable from the OBD-II port.

143. Check all fluid levels before operating vehicle.

Congratulations on the installation of your new Edelbrock E-Force Supercharger System. If you have any questions, please call our **Technical Support hotline at 1-800-416-8628** and one of our technicians will be happy to assist you.



**Edelbrock Supercharger  
2007-2012 GM SUV 4.8L, 5.3, 6.0L, 6.2L**

**Installation Instructions**

**E-mail Edelbrock Your Stock Vehicle Calibration**

In the rare occurrence that you encounter an error message that reads “Calibration not supported” during the test flash procedure on page 11, you will need to e-mail Edelbrock your stock vehicle calibration to [Calibration@Edelbrock.com](mailto:Calibration@Edelbrock.com). Otherwise, disregard this step.

- Begin by downloading the SCT device updater software to your computer; it can be downloaded from: <http://www.sctflash.com/software/SCTDeviceUpdater.exe>.
- Put the car into Acc mode but do not start it.
- Connect the supplied PCM cable from the tuner to the OBD-II connector.
- Select PROGRAM VEHICLE, arrow over to UPLOAD STOCK, press SELECT and follow the prompts on the screen.
- If the upload fails, you will be asked to AUTO DETECT, press SELECT and follow the prompts on the screen. If the auto detect fail, then please contact Edelbrock Tech support @ 800-416-8628.
- Once the stock calibration has loaded, disconnect the programmer from the OBD-II connector and connect it to your PC using the supplied USB cable.
- Open the SCT software and select the button on the lower left hand side that reads GET STOCK FILE FROM DEVICE. Follow the instructions on the screen.
- Once the download is complete call 1-800-416-8628 and our tech support staff will assist you in e-mailing the file to [calibration@edelbrock.com](mailto:calibration@edelbrock.com). **NOTE:** The subject line of your e-mail should be “file update needed”, The file will automatically be labeled using your VIN # followed by “.sul “ (XXXXXXXXXXXXX.sul).
- Once we have this file we can update the tune to work with your application, then we will e- mail you the custom tune which you may use until the release version is available. (This process can usually be completed within 1 to 2 business days).
- Download the new tune to the programmer using the directions received with the custom tune.
- Re-try the test flash procedure using the custom tune.



**Edelbrock LLC, 2700 California Street, Torrance, CA 90503  
Toll-Free Tech Line: 1-800-416-8628**